

Simulation output

For each simulation run, a new output folder is created in the simulation output folder. The created folder has the name of the input file. In addition date-time is added to the folder name if the option is selected in Options→Expert settings of nextnanomat (this option is recommended in order to avoid overwritten existing output data). The created output folder contains:

- the **input file** (.in).
- a folder '...' which gives material parameters used in the calculation.
- a folder ... (only if the strain option is activated).
- Several files related to the sweep made. For a voltage sweep, it contains
- a **log file** is created at the end of the simulation, containing all the information displayed during the simulation.

From:

<https://nextnano-docu.northeurope.cloudapp.azure.com/dokuwiki/> - **nextnano.QCL - Software for Quantum Cascade Lasers**

Permanent link:

https://nextnano-docu.northeurope.cloudapp.azure.com/dokuwiki/doku.php?id=nnp:simulation_output

Last update: **2019/06/24 10:21**

