

Optics: gain/absorption calculation

There are two different kind of gain/absorption calculations which can be made in nextnano.NEGF:

- the semiclassical one uses the populations and the linewidths calculated from the NEGF steady-state solution to calculate the gain/absorption in a semiclassical way;
- linear response theory to an a.c. incoming field. In this case, time-dependent Green's functions are considered.

Semiclassical gain/absorption calculation

From the Green's functions calculated in steady-state, the populations are extracted in the Wannier-Stark basis. The linewidths are also calculated in this basis. The semiclassical gain/absorption spectrum is then calculated according to:

```
## g(\hbar \omega) = \sum_{i \neq j} (\rho_j - \rho_i) \sim d_{ij}^2 \sim
\frac{\Gamma_{ij}}{(\hbar\omega - E_{ij})^2 + \Gamma_{ij}^2/4} \frac{e^2 \sim E_{ij}}{\hbar \sim \epsilon_0 \sqrt{\epsilon_r} \sim c}
```

where

- ρ_i is the electron density in the state i . $\rho_i = p_i \sim n_{3D}$ where p_i is the normalized population in state i and n_{3D} the averaged 3D electron density.
- $E_{ij} = E_j - E_i$ is the transition energy between states i and j .
- d_{ij} is the dipole of the transition. $d_{ij} = \int dz \sim |\psi_j(z)| \sim z \sim |\psi_i(z)|$.
- Γ_{ij} is the linewidth (full half at half maximum) of the transition calculated from the NEGF steady state
- ϵ_r is the relative permittivity
- ϵ_0 is the vacuum permittivity
- e is the elementary charge.

Gain/absorption calculation from linear response theory to an a.c. field

In this case the perturbation due to an a.c. electric field along z is considered. The perturbing Hamiltonian reads in the Lorenz Gauge: $H_{ac} = e \sim z \sim E e^{-i\omega t}$ where the amplitude E of the electric field is small and can be considered as a perturbation. The response Green's function $\delta G^{<}(E, \omega)$ is calculated within linear response theory. As shown by Wacker (Phys. Rev. B 66, 085336 (2002)), the Green's function linear response reads: $\delta G^{<}(E, \omega) = G^{<}(E + i\hbar\omega) (H_{ac} + \delta \Sigma^{<} R(E, \omega)) G^{<}(E)$

$$\delta G^{<}(E, \omega) = G^{<}(E + i\hbar\omega) H_{ac} + G^{<}(E + i\hbar\omega) H_{ac} G^{<}(E) + G^{<}(E + i\hbar\omega) H_{ac} G^{<}(E) + G^{<}(E + i\hbar\omega) \delta \Sigma^{<} R(E, \omega) G^{<}(E) + G^{<}(E + i\hbar\omega) \delta \Sigma^{<} R(E, \omega) G^{<}(E) + G^{<}(E + i\hbar\omega) \delta \Sigma^{<} A(E, \omega) G^{<}(E) + G^{<}(E + i\hbar\omega) \delta \Sigma^{<} A(E, \omega) G^{<}(E)$$

Permittivity and gain/absorption

The bulk relative permittivity, or dielectric constant, is assumed to be given by the [Lyddane-Sachs-Teller relation](#):

$$\$ \$ \epsilon^{\text{bulk}}(\omega) = \epsilon_{\infty} + (\epsilon_{\infty} - \epsilon_{\text{static}}) \frac{\omega_{\text{TO}}}{\omega^2 - \omega_{\text{TO}}^2} \$ \$$$

In the self-consistent gain calculation, the quantity which is actually calculated is the a.c. conductivity $\sigma(\omega)$.

The complex relative permittivity which is output is then:

$$\$ \$ \epsilon_r(\omega) = \epsilon^{\text{bulk}}(\omega) - i \frac{\sigma(\omega)}{\omega \epsilon_0} \$ \$$$

Finally the gain reads

$$\$ \$ g(\omega) = -\frac{\text{Re}(\sigma(\omega))}{\epsilon_r(\omega)} \$ \$$$

From:

<https://nextnano-docu.northeurope.cloudapp.azure.com/dokuwiki/> - **nextnano.NEGF - Software for Quantum Transport**



Permanent link:

<https://nextnano-docu.northeurope.cloudapp.azure.com/dokuwiki/doku.php?id=qcl:optics&rev=1607703662>

Last update: **2020/12/11 16:21**